0563Z–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Main switch cannot be turned ON. (Cruise indicator light in combination meter are not lit.)	3. Cruise control switch circuit 4. Spiral cable 5. Wire harness 6. Cruise main indicator light circuit 7. ECM	05–1307 05–755 01–31 05–1310 01–31
Vehicle speed setting cannot be done. (Although indicator light in combination meter is lit when the main switch is turned ON, they go off when vehicle speed is set.)	1. Cruise control switch circuit 2. Spiral cable 3. Wire harness 4. ECM	05–1307 05–755 01–31 01–31
Setting cannot be done. (Indicator light in combination meter is lit when the main switch is turned ON and they remain ON while setting.)	1. Cruise control switch circuit 2. Spiral cable 3. Stop light switch circuit 4. Park/Neutral position switch circuit 5. Wire harness 6. Combination meter system 7. ECM	05–1307 05–755 05–1302 05–1312 01–31 05–1168 01–31
While the vehicle is driving with cruise control, the set control is canceled. (Indicator light and CRUISE remain ON.)	1. Cruise control switch circuit 2. Spiral cable 3. Vehicle speed sensor circuit 4. Stop light switch circuit 5. Cruise main indicator light circuit 6. Park/Neutral position switch circuit 7. Wire harness 8. ECM	05–1307 05–755 05–1299 05–1302 05–1310 05–1312 01–31 01–31
Hunting (Speed is not constant.)	1. Vehicle speed sensor circuit 2. Malfunction in speedometer circuit 3. ECM	05–1299 05–1168 01–31
Setting cannot be cancelled. (When Coast, Acceleration, Resume, Set speed change and Control switch are operated.)	1. Cruise control switch circuit 2. Spiral cable 3. Wire harness 4. ECM	05–1307 05–755 01–31 01–31