STEERING SENSOR

REPLACEMENT

320DS–01

1. **PRECAUTION(See page 60–24)**
2. **SEPARATE BATTERY NEGATIVE TERMINAL(See page 60–24)**
3. **PLACE FRONT WHEELS FACING STRAIGHT AHEAD(See page 60–24)**
4. **REMOVE STEERING WHEEL COVER LOWER NO.2**
   (See page 60–24)
5. **REMOVE HORN BUTTON ASSY**
   (See page 60–24)
6. **REMOVE STEERING WHEEL ASSY**
   (See page 60–24)
   SST 09950–50013 (09951–05010, 09952–05010, 09953–05020, 09954–05021)
7. **REMOVE INSTRUMENT CLUSTER FINISH PANEL**
   (See page 60–24)
8. **REMOVE STEERING COLUMN COVER**
   (See page 60–24)
9. **REMOVE SPIRAL CABLE SUB–ASSY**
   (See page 60–24)
10. **REMOVE STEERING SENSOR**

11. **INSTALL STEERING SENSOR**

12. **INSPECT SPIRAL CABLE SUB–ASSY**

(a) If the following condition is identified, replace the spiral cable sub–assy with new one.
Condition:
Scratches or cracks on the connector
Cracks, dents or chipping of the spiral cable sub–assy

13. **PLACE FRONT WHEELS FACING STRAIGHT AHEAD(See page 60–24)**
14. **INSTALL SPIRAL CABLE SUB–ASSY**
    (See page 60–24)
15. **CENTER SPIRAL CABLE(See page 60–24)**
16. **INSTALL STEERING WHEEL ASSY**
    (See page 60–24)
17. **INSTALL HORN BUTTON ASSY**
    (See page 60–24)
18. **INSPECT HORN BUTTON ASSY**
    (See page 60–24)
19. **INSPECT SRS WARNING LIGHT(See page 05–511)**