
6902Q–03

INSPECTION



1. INSPECT HORN RELAY ASSY

(a) Inspect the horn relay (Marking: HORN) continuity.

Condition	Tester connection	Specified condition
Constant	1 ⇔ 2	Continuity
Constant	3 ⇔ 5	No continuity
Apply B+ between terminals 1 and 2	3 ⇔ 5	Continuity

If the continuity is not as specified, replace the relay.