700BK–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Rear window defogger does not operate (Indicator lamp on)	1. DEF fuse (Instrument panel J/B)	68–1
	2. GAUGE 2 fuse (Instrument panel J/B)	68–1
	3. DEF relay (Instrument panel J/B)	70–19
	4. Rear window defogger wire	–
	5. Wire harness	–
	6. ECM (1AZ–FE)	05–21
	7. ECM (2AZ–FE)	05–150
	8. ECM (1MZ–FE)	05–308
Rear window defogger does not operate (Indicator lamp off)	1. HTR fuse (Instrument panel J/B)	68–1
	2. Defogger switch (Heater control housing)	05–694
	3. Wire harness	–
	4. Heater control base	05–694