■CONSTRUCTION AND OPERATION

Combination Meter

- The master warning light, PCS warning light, warning message of the multi-information display and buzzer in the combination meter warns the driver of the abnormal or poor conditions of the pre-crash safety system.
- Two types of warning messages are used for the pre-crash safety system, as described below. The pre-crash safety system will not operate when these messages appear in the combination meter.

Warning Message	Detail			Buzzer	DTC
	This message appears when the seat belt control ECU detects a system malfunction.	Illuminate	Illuminate	Sounds once	○
	This message appears when the seat belt control ECU determines the following conditions: ● Dirty millimeter wave radar sensor ● Poor weather condition ● Overheated seat belt control ECU After these conditions have been resolved, the system will operate normally.	Illuminate	Flash	Sounds once	X

○: Repair is required/DTC are output
X: Repair is not required/DTC are not output