■CUSTOMIZED BODY ELECTRONICS SYSTEM

An intelligent tester II can be used to customize the system settings.

System	Intelligent Tester II Display Content	Contents	Default Setting	Available Setting
Wireless Door Lock	Trunk Lid Operation	To change the operation method of opening the trunk by the transmitter.	0.8s PR	1 TIME/ 2 TIMES /0.8s PR /OFF
	Wireless Control	Function to turn ON/OFF of the wireless door lock.	ON	ON/OFF
	Hazard Answer Back	Function to turn ON/OFF of the hazard answer back of the wireless door lock.	ON	ON/OFF
	Auto Lock Time	Function to change the time until re-locking after unlocking with the wireless door lock.	30 sec	30 sec /60 sec
Power Window	Door Key P/W Up	Function to make all the door windows up manually by holding the driver's side door key to the lock side for 1.5 seconds when ignition switch is OFF.	ON	ON/OFF
	Door Key P/W Down	Function to make all the door windows down manually by holding the driver's side door key to the unlock side for 1.5 seconds when ignition switch is OFF.	ON	ON/OFF
	P/W Up W/Transmit	Function to make all the door windows up manually by pressing on the transmitter lock button for 2.5 seconds when ignition switch is OFF.	ON	ON/OFF
	P/W Down W/Transmit	Function to make all the door windows down manually by pressing on the transmitter unlock button for 2.5 seconds when ignition switch is OFF.	ON	ON/OFF
Illuminated Entry	Lighting Time	Function to change the lighting time after closing the door. (It will quickly fade out in the event the ignition switch is turned ON.)	15 sec	7.5 sec/ 15 sec/ 30 sec
	I/L when ACC OFF	Function to light up the interior lights when ignition switch is turned from "ACC" to "OFF".	ON	ON/OFF
	I/L ON W/ Door Key Unlock	Function to light up the interior lights when unlocking with the door key cylinder.	ON	ON/OFF
Warning	Seat Belt Warning	Function to change the seat-belt warning buzzer.	D/P ON	D/P ON/ D ON/ P ON/ D/P OFF

(Continued)

System	Intelligent Tester II Display Content	Contents	Default Setting	Available Setting
Light Control	Response Time	To change the delay timing of lighting the taillight when going into the tunnel in case that the light control switch is at AUTO position.	0.15 sec	1.0 sec/ 0.15sec
	Disp Ex ON Sen	To change the brightness of lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
	Disp Ex OFF Sen	To change the brightness of canceling the lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	NORMAL	LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2
Slide Roof*	Door Key Related Open	Function to open the sliding roof manually linking with the power window if holding the driver side door key for 1.5 seconds or more to the unlock side when the ignition switch is OFF.	ON	ON/OFF
	Door Key Related Close	Function to close the sliding roof manually linking with the power window if holding the driver side door key for 1.5 seconds or more to the lock side when the ignition switch is OFF.	ON	ON/OFF
	Wireless Key Related Open	Function to open the sliding roof manually linking with the power window if pressing on the transmitter unlock button for 1.5 seconds or more when the ignition switch is OFF.	ON	ON/OFF
	Wireless Key Related Close	Function to close the sliding roof manually linking with the power window if pressing on the transmitter lock button for 1.5 seconds or more when the ignition switch is OFF.	ON	ON/OFF
	Door Key Related Operation	Function to select the opening direction of the manual opening of the sliding roof linking with the power window if holding the driver side door key for 1.5 seconds or more to the unlock side when the ignition switch is OFF.	SLIDE	TILT/ SLIDE
	Wireless Key Related Operation	Function to select the opening direction of the manual opening of the sliding roof linking with the power window if pressing on the transmitter unlock button for 1.5 seconds or more when the ignition switch is OFF.	SLIDE	TILT/ SLIDE
A/C	Set Temperature Shift	To control with the shifted temperature against the display temperature.	NORMAL	+2°C/ +1°C/ NORMAL/ –1°C/ –2°C
	Air Inlet Mode	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to RECIRCULATED mode.	AUTO	MANUAL/ AUTO
	Compressor Mode	Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	AUTO	MANUAL/ AUTO

(Continued)

System	Intelligent Tester II Display Content	Contents	Default Setting	Available Setting
A/C	Compressor/Air Inlet DEF operation	Function to turn the A/C ON automatically linking with the FRONT DEF button when A/C OFF.	LINK	NORMAL/ LINK
	Evaporator Control	Function to set the evaporator control to the AUTOMATIC position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	AUTO	MANUAL/ AUTO
	Foot/DEF Auto Mode	Function to turn the air flow from FOOT/DEF ON automatically when AUTO MODE is ON.	ON	OFF/ON
	Foot/DEF Automatic Blow Up Function	Function to switch the blower level automatically when the defroster is ON.	ON	OFF/ON
	Ambient Temperature Shift	To control with the shifted ambient temperature against the display ambient temperature.	NORMAL	+3°C/ +2°C/ +1°C/ NORMAL/ –1°C/ –2°C/ –3°C

*: Only for Models with Sliding Roof system