■ FUNCTION

1. General

The wireless door lock remote control system has following functions:

Function	Outline
All Doors Lock	Pressing the LOCK button of the transmitter lock all doors.
All Doors Unlock	Pressing the UNLOCK button of the transmitter unlocks all doors.
Trunk Opener*	Keeping the TRUNK button of the transmitter pressed longer about 0.6 seconds opens the trunk lid.
Answer Back*	The hazard light flashes once when locking, and flashes twice when unlocking, to inform that the operation has been completed.
Automatic Lock*	If none of the doors are opened within 30 seconds of being unlocked by the wireless door lock remote control, all the doors will be locked again automatically.
Repeat	If a door is not locked in response to the locking operation of the transmitter, the integration relay will output a lock signal after the unlock operation.
Illuminated Entry*	When all the doors are locked, pressing the UNLOCK button causes the interior lights to illuminate simultaneously with the unlock operation.
Transmitter Recognition Code Registration Function	Enables the registering (writing or storing) of 6 types of transmitter recognition codes in the EEPROM that is contained in the integration relay.

*: The setting function can be changed using the customized body electronics system. For details, refer to Customized Body Electrical System section on page BE-9.

2. Transmitter Recognition Code Registration Function

The table below shows the 6 special code ID registration function modes through which up to 6 different codes can be registered. The codes are electrically registered (written to and stored) in the EEPROM. For details of the recognition code registration procedure, refer to the Camry Repair Manual (Pub. No. RM0260E).

Mode	Function
Rewrite Mode	Erases all previously registered codes and registers only the newly received codes. This mode is used whenever a transmitter or the wireless door lock receiver is replaced.
Add Mode	Adds a newly received code while preserving any previously registered codes. This mode is used when adding a new transmitter. If the number of codes exceeds 6, the oldest registered code is erased first.
Confirm Mode	Confirms how many codes are currently registered. When adding a new code, this mode is used to check how many codes already exist.
Prohibit Mode	To delete all the registered codes and to prohibit the wireless door lock function. This mode is used when the transmitter is lost.