THEFT DETERRENT SYSTEM

■ DESCRIPTION

- The theft deterrent system sounds an alarm when any of the following activates are detected:
  - The vehicle being forcibly entered.
  - The engine hood or trunk lid being opened.
  - A door or trunk lid being unlocked without the key.
  - The battery terminals are removed and reconnected.
- The system consists of door lock control system parts, wireless door lock remote control system parts, security horn and security indicator light.
- The main body ECU controls this system.
- The warning methods and timing of the system are listed below.

Warning Method	Interior Light	Illuminates
	Hazard Light	Flashing
	Vehicle Horn	Sound (approx. 0.4 second cycles)
	Security Horn	Sound (approx. 0.4 second cycles)
	Door Lock Motor	Locking
Warning Time		30 seconds