■ FUNCTION

The theft deterrent system has the following function:

Function	Outline
Alarm	When the theft deterrent system is enters the alarm state, the warning items (interior light, hazard warning lights and security horn) are operated for approximately 30 seconds.
Vehicle Horn Alarm	When the theft deterrent system is enters the alarm state, the vehicle horn is operated for approximately 30 seconds.
Alarm Indicator	When the state of the theft deterrent system enters the armed preparation or alarm state, the security indicator light is illuminated to inform the user. This indicator is also the engine immobilizer indicator, it blinks when the engine immobilizer is in an engaged state.
Forced Door Lock	The main body ECU transmits a door lock signal to all the doors when all the following conditions are satisfied. ● The theft deterrent system is in the alarm state. ● Either the front door is unlocked without using the mechanical key. The function stops when one of the following conditions is met. ● All doors are locked. (lock function of door lock or transmitter is operated). ● The warning ends after approximately 30 seconds.