## ■ ACTUATION AREA

The special functions of the entry & start system only work when the key is in the actuation area formed by the 6 oscillators.

- The front and rear room oscillators form the actuation area of the push button start function.
- Front door oscillators and inner and outer trunk oscillators form the actuation area of the entry function.

