Power Source

Front Heater (Except Europe)

1 2 3 4

* 1 : 24 Volts in Series Connection
* 2 : Israel, Taiwan, 1BZ-FPE
* 3 : Except *2, *8, *14
* 4 : Cold Area Spec.
* 5 : LHD N04C-TQ
* 6 : 12 Volts in Parallel Connection
* 8 : N04C-UH
* 9 : Except *8 *14
*10 : Before Aug. 2011 Production
*11 : From Aug. 2011 Production
*12 : Before Jan. 2015 Production
*13 : From Jan. 2015 Production
*14 : N04C-VL

ACC
AM1
IG1
ST1
I 3
Ignition SW
IJ1
F16
Fuse Block
60A AM RR
50A AM FR
60A AM1
140A ALT (*8, *14)
100A ALT (*3)
120A ALT (*2)
FL MAIN
3. 0W
Battery
(12 Volts)
30A FR-HEATER
10A GAUGE
30A RR-HEATER
FR-HTR Relay
WATER PUMP Relay
J13(A), J14(B), J47(C), J48(D) Junction Connector
J 7 Junction Connector
F 3 Front Heater
F 4 Front Heater Blower Resistor
H 6 Heater Blower SW
HI
M2
M1
LO
OFF
IH1
IH3
IH4
IJ5
M 2 Max Warm SW
10A WATER PUMP
H 8 Heater Pump
J10 Junction Connector
Instrument Panel Right (LHD) Instrument Panel Left (RHD)
Floor Cross Member No. 5 Center