Power Source

Illumination (Europe)

1 2 3 4

I 3 Ignition SW

ACC 3 IG1 2 ST1 AM1 4

D21 Diode (Ignition)

TAIL Relay

Taillight System<49-2>

7. 5A TAIL (RH)

7. 5A TAIL (LH)

J13(A), J14(B) Junction Connector

T 2 Tachograph

J 8 Junction Connector

R25 Rear Fog Lamp SW

ILL+ E

H 1 Hazard SW

R 2 Rear Heater SW

R 5 Room Light SW No. 1

R 6 Room Light SW No. 2

H 6 Heater Blower SW

A 8 A/C Control SW

R 3 Rear Window Defogger SW

D27 DPF SW

C 4(B), C 5(C), C25(E) Combination Meter

Engine Stop System<51-1>

ENGINE STOP Relay

F16 Fuse Block 60A AM1 100A ALT

CIRCUIT OPENING Relay

FL 0. 5G

Battery

J10 Junction Connector

Starting System<45-2>

M 5(E), M 6(B), M 7(C), M 8(D), M 9(A) Main Relay

J 7 Junction Connector

Tail

Illumination

CPU

EB *3 BE *3 ID *2 IC *1 EA Near the Glow Plug No. 4

* 1 : Instrument Panel Right (RHD)
Instrument Panel Left (LHD)
* 2 : Instrument Panel Right (LHD)
Instrument Panel Left (RHD)
* 3 : Floor Cross Member No. 5 Center
* 4 : Before Aug. 2009 Production
* 5 : From Aug. 2009 Production
* 6 : Before Aug. 2007 Production
* 7 : From Aug. 2007 Production