
Engine Stop System (1BZ-FPE)
Ignition (1BZ-FPE)
Engine Control (1BZ-FPE)
Engine Control (1BZ-FPE)
Engine Control (1BZ-FPE)
Engine Control (1BZ-FPE)
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
A51(A),B76(B),B77(C)
ECM
LPGR
+B
BATT
PHRY
MREL
IGF
IGT
NE
NE-
ELS2
ELS
SIL
TE1
VF
W
FC
ISC
ISC2
ISC3
ISC4
FCM1
FCM2
FCM3
FCM4
NSW
STA
ACT
AC1
E1
PS
OX1B
HT1B
OX1A
HT1A
IDL
VTA
VC
PIM
THW
THA
E2
IGSW
#10
#20
E01
SPD
7.5A
IGN
NO.2
20A
EFI-
MAIN
50A
HTR
SUB
15A
INJ
7.5A
IGN
NO.1
5A
METER-IG2
15A
DOME
ENG MAIN
/LPG
Relay
EFI
Relay
A41
Pre Heater Relay
A33
Battery Relay
A80
No. 3
Junction Connector
A14
Door Control Switch Assembly
ENG STOP/
P LOCK NO.2
Relay
B39
Ignition Coil Assembly
B29
Distributor Assembly
TAIL Fuse
<27-4>
STOP NO.5 Fuse
<24-2>
DLC3
<18-2>
DLC3
<18-3>
B122
No. 48 Junction Connector
A83
No. 6 Junction Connector
B41
No. 2 Fuel Cut Off Valve Assembly
B38
LPG Idle Speed Control
Valve Assembly
B36
Air Fuel Ratio Control
Motor Assembly
ST Relay
<8-3>
Air Conditioning
Amplifier Assembly
<56-18>
B112
No. 45
Junction Connector
B30
Power Steering Oil Pressure Switch
A62
Oxygen Sensor
B35
No. 2 Oxygen Sensor
B31
Throttle Position Sensor
B28
E.F.I. Vacuum Sensor Assembly
B6
E.F.I. Engine Coolant Temperature Sensor
B33
E.F.I. Intake Air Temperature Sensor
A82
No. 5 Junction Connector
B42
Solenoid Resistor
Combination Meter Assembly
<52-6>
J77(A),J78(B)
No. 29
Junction Connector
Check Engine
CPU
J1(A)
Combination Meter Assembly
CHK
ES
J68(A)
No. 67 Junction Connector
A42
LPG Solenoid Valve
A82
No. 5
Junction Connector
B40
LPG Pre Heater Assembly
J35
Emergency Switch
J80
No. 30 Junction Connector
A84
No. 7 Junction Connector
B34
Igniter Assembly
B43
Check Connector
Combination Meter
Assembly <52-3>
B37
LPG Injector Assembly
(Shielded)