(Cont. next page) 16 COASTER (Cont'd)

(Cont. next page) 16 COASTER (Cont'd)

(Cont. next page) 16 COASTER (Cont'd)

(Cont. next page) 16 COASTER (Cont'd)

(Cont. next page) 16 COASTER (Cont'd)

Engine Stop System (1BZ-FPE)

Ignition (1BZ-FPE)

Engine Control (1BZ-FPE)

Engine Control (1BZ-FPE)

Engine Control (1BZ-FPE)

Engine Control (1BZ-FPE)

Engine Control (1BZ-FPE)

* 1 Wires to ECU Protector
* 2 Wires to ECU Protector

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24