ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
A/T	=	Automatic Transmission
COMB.	=	Combination
ECT	=	Electronic Controlled Transmission
ECU	=	Electronic Control Unit
Ex.	=	Except
FL	=	Fusible Link
IG	=	Ignition
LH	=	Left-Hand
LHD	=	Left-Hand Drive
M/T	=	Manual Transmission
O/D	=	Overdrive
R/B	=	Relay Block
RH	=	Right-Hand
RHD	=	Right-Hand Drive
SW	=	Switch
TEMP.	=	Temperature
TP	=	Throttle Position
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without