ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
ABS	=	Anti–Lock Brake System
COMB.	=	Combination
DLC3	=	Data Link Connector 3
ECU	=	Electronic Control Unit
EDU	=	Electronic Driving Unit
EFI	=	Electronic Fuel Injection
EGR	=	Exhaust Gas Recirculation
FL	=	Fusible Link
ISC	=	Idle Speed Control
LH	=	Left–Hand
LHD	=	Left–Hand Drive
R/B	=	Relay Block
RH	=	Right–Hand
RHD	=	Right–Hand Drive
SPEC.	=	Specification
SW	=	Switch
TEMP.	=	Temperature
VRV	=	Vacuum Regulating Valve
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.