G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Magnetic Clutch	90980–11271
A 2	Alternator	90980–11349
A 3	Alternator (1HZ, 15B–FT, 14B)	90980–09201
	Alternator (3RZ–FE China, 15B–FTE RHD)	90980–09212
	Alternator (3RZ–FE Except China, 15B–FTE LHD)	90980–09363
A 4	Automatic Door Control ECU (LHD Gliding Door Type)	90980–10897
A 5	Automatic Door Control ECU (LHD Gliding Door Type)	90980–11022
A 6	Automatic Door Emergency SW	90980–10157
A 7	A/C Amplifier	90980–10801
A 8	A/C Control SW	90980–10807
A 9	A/C Magnetic Clutch Relay	90980–10171
A10	Accel Inter–Lock (LHD)	90980–11001
	Accel Inter–Lock (RHD)	90980–10795
A11	Accel Inter–Lock Relay No.1	90980–10173
A12	Accel Inter–Lock Relay No.2	
A13	Accel SW	90980–10906
A14	Air Cleaner Warning Sensor	90980–11025
A15	Automatic Door Control SW	90980–11013
A16	Automatic Door Relay	90980–10173
A17	A/C Condenser Fan Motor No.1	90980–10928
A18	A/C Condenser Fan Motor No.2	
A20	A/C Dual Pressure SW	90980–10943
A21	A/C Thermistor	90980–10498
A22	Air Inlet Control Servo Motor	–
A23	Air Vent Mode Control Servo Motor	90980–10825
A24	Automatic Door Control ECU (Folding Door Type)	90980–11240
A25	Automatic Door Control ECU (RHD Gliding Door Type)	90980–10897
A26	Automatic Door Control ECU (RHD Gliding Door Type)	90980–11022
A28	Automatic Door Warning Buzzer	90980–10887
A29	Automatic Door Relay No.2 (RHD Gliding Door Type)	90980–10175
A30	Automatic Door Relay No.3 (RHD Gliding Door Type)	90980–10171
A31	ABS Speed Sensor Front LH	90980–11075
A32	ABS Speed Sensor Front RH	
A33	ABS Actuator	90980–11698
A34	ABS Actuator	90980–11413
A41	ABS Speed Sensor Rear	90980–10942
A42	Accel Position Sensor	90980–11232
A43	Accelerator Pedal SW	90980–10825
A44	ABS ECU	90980–11390
A45	ABS ECU	90980–11391
A46	ABS ECU	90980–11408
A47	ABS ECU	90980–11392
B 1	Back–Up Light SW	90980–11250
B 3	Brake Oil Level SW	90980–10825
B 4	Brake Vacuum Warning Buzzer	
B 5	Buckle SW	90980–11490
B 7	Back Door Courtesy SW (Luggage Room Type)	90980–11146
B 8	Blower Mode Relay No.1	90980–10171
B 9	Blower Mode Relay No.1	
B10	Blower Mode Relay No.2	
B11	Blower Mode Relay No.2	
B12	Blower Mode Relay No.3	
B13	Blower Mode Relay No.3	
B14	Blower Motor No.1	90980–10214
B15	Blower Motor No.2	
B16	Blower Motor No.3	
B17	Blower Resistor No.1	90980–10171
B18	Blower Resistor No.2	
B19	Blower Resistor No.3	
B20	Battery Relay	
B21	Back Door Courtesy SW (Leaf Door Type)	90980–10444
B22	Battery Relay	90980–10170
C 1	Check Connector	90980–11195
C 2	Cigarette Lighter	90980–10760
C 3	Combination Meter	90980–11114
C 4	Combination Meter	90980–11113
C 5	Combination Meter	90980–11115
C 6	Combination SW	90980–11224
C 7	Combination SW	90980–11225
C 8	Center Door Courtesy SW (Folding Type)	90980–11146
C 9	Center Door Courtesy SW Front (Gliding Door Type)	90980–11189
C10	Center Door Courtesy SW Rear (Gliding Door Type)	90980–11146
C11	Clock	90980–10795
C12	Cool Box	90980–10908
C16	Camshaft Position Sensor	90980–11250
C17	Crankshaft Position Sensor (15B–FTE)	90980–11162
	Crankshaft Position Sensor (3RZ–FE)	90980–11016
C18	Center Side Marker Light LH	90980–11149
C19	Center Side Marker Light RH	
D 1	DC/DC Converter	90980–10799
D 2	Destination Display SW	90980–10127
D 3	Diode (A/C)	90980–10962
D 4	Diode (Center Door No.1)	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
D 5	Diode (Center Door No.2)	90980–11071
D 6	Diode (Exhaust Brake)	
D 8	Diode (Step Light)	
D 9	Destination Display	90980–10216
D10	Door Lock Opener Motor	90980–10795
D11	Diode (Parking Brake)	90980–10962
D12	Diode (Center Door No.3)	
D13	Diode (Exhaust Brake Retarder Solenoid)	
D14	Diode (Center Door No.4)	90980–11071
D15	Door Lock Control Relay	90980–10062
D16	Door Lock Motor	90980–11292
D17	Door Lock Relay	90980–10173
D18	Diode (Surge)	90980–10962
D19	DLC3	90080–98012
E 2	Engine Oil Level Sensor	90980–10532
E 3	Engine Stop SW	90980–11410
E 4	Exhaust Brake Retarder Solenoid	90980–10887
E 5	Exhaust Neutral SW	90980–11142
E 8	Emergency Door Warning Buzzer	90980–10860
E 9	Exhaust Brake Clutch SW	90980–10906
E10	Exhaust Brake ECU	90980–10803
E13	Emergency Door Courtesy SW	90980–11146
E14	Emergency Door SW	90980–10182
E15	Emergency Door Courtesy SW No.2	90980–11146
E16	Emergency Door Light	90980–10906
E17	EDU	90980–11024
E18	EFI Water Temp. Sensor	90980–10737
E19	Emergency SW	90980–10171
E20	Engine ECU (15B–FTE)	90980–11421
	Engine ECU (3RZ–FE)	90980–11390
E21	Engine ECU	90980–11476
E22	Engine ECU (15B–FTE)	90980–11637
	Engine ECU (3RZ–FE)	90980–11391
E23	Engine ECU	90980–11638
E24	Engine ECU	90980–11424
F 1	Front Door Courtesy Light	90980–10121
F 2	Front Door Courtesy SW	90980–10434
F 3	Front Heater	90980–10214
F 4	Front Heater Blower Resistor	90980–10173
F 5	Front Turn Signal Light and Clearance Light LH	90980–10942
F 6	Front Turn Signal Light and Clearance Light RH	
F 7	Front Washer Motor	90980–10980
F 8	Front Wiper Motor	90980–11194
F10	Fuel Sedimentary Warning Buzzer	90980–10056

Code	Part Name	Part Number
F11	Front Speaker LH	90980–10935
F12	Front Speaker RH	
F13	Fuel Heater	90980–10928
F14	Fuel Sedimentary SW	90980–11003
F15	Fuel Sender	90980–11245
F16	Fuse Block (LHD)	82620–36090
	Fuse Block (RHD)	82620–36080
F19	Fuel Cut Solenoid	90980–11149
F20	Front Fog Light LH	90980–11051
F21	Front Fog Light RH	
F22	Fuel Temp. Sensor	90980–10737
F23	Fuel Pump	90980–11410
F24	Front Side Marker Light LH	90980–11149
F25	Front Side Marker Light RH	
G 1	Glow Plug	99141–13004
G 4	Glow Plug Relay (Main)	90980–10498
G 5	Glow Plug Relay (Main)	90980–09567
G 6	Glow Plug Relay (Main)	
G 7	Glow Plug Relay (Sub)	90980–11288
H 1	Hazard SW	90980–10801
H 2	Headlight LH (Hi)	90980–11314
H 3	Headlight LH (Hi–Lo)	
H 4	Headlight RH (Hi)	
H 5	Headlight RH (Hi–Lo)	
H 6	Heater Blower SW	90980–10714
H 7	Horn	90980–10619
H 8	Heater Pump	90980–11410
H 9	High Mounted Stop Light	90980–11159
H10	Heated Oxygen Sensor	90980–11028
I 1	Injector Pump	90980–11157
I 2	Intake Heater	99141–13006
I 3	Ignition SW	90980–10873
I 6	Igniter and Ignition Coil No.1	90980–11150
I 7	Igniter and Ignition Coil No.2	
I 8	Injection Pump	90980–11028
I 9	Injector No.1	90980–11153
I10	Injector No.2	
I11	Injector No.3	
I12	Injector No.4	
I13	Intake Air Temp. Sensor (15B–FTE)	90980–11025
	Intake Air Temp. Sensor (3RZ–FE)	90980–11163
I14	ISC Valve	90980–11145
J 7	Junction Connector	90980–11398
J 8	Junction Connector	
J 9	Junction Connector	90980–11391

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
J10	Junction Connector	90980–11398
K 1	Knock Sensor	90980–11166
L 1	License Plate Light (Luggage Room Type)	90980–11148
L 2	License Plate Light LH (Double–Leaf Door Type)	90980–10825
L 3	License Plate Light RH (Double–Leaf Door Type)	
L 4	Luggage Room Light	90980–10121
M 2	Max Warm SW	90980–10825
M 3	Master Cylinder Pressure Sensor	90980–10845
O 1	Oil Pressure SW (1HZ)	90980–10359
	Oil Pressure SW (15B–FTE, 15B–FT)	90980–11363
O 2	Oil Pressure SW	90980–11363
O 5	Oil Pressure SW	
P 1	Parking Brake SW (Except 3RZ–FE)	90980–10795
	Parking Brake SW (3RZ–FE)	90980–10860
P 2	Pre–Heating Timer (Fixed Delay Type)	90980–10797
P 3	Pre–Heating Timer (Intake Heater)	90980–10799
P 4	Pre–Heating Timer (Super Glow Type)	90980–10803
P 5	Pick–Up Sensor	90980–11162
P 6	Pre–Heating Timer (15B–FT)	90980–10803
P 7	Power Steering Oil Pressure SW	90980–11428
R 1	Radio	90980–10997
R 2	Rear Heater SW	90980–10463
R 3	Rear Window Defogger SW	90980–10797
R 4	Room Light Control SW or Short Pin	90980–10789
R 5	Room Light SW No.1	90980–10797
R 6	Room Light SW No.2	90980–10799
R 7	Rear Combination Light LH	90980–10988
R 8	Rear Combination Light RH	
R 9	Rear Heater Motor No.1	90980–11022
R10	Rear Heater Motor No.2	
R11	Rear Speaker LH	90980–10935
R12	Rear Speaker RH	
R13	Rear Washer Motor	90980–10980
R14	Rear Window Defogger (Double–Left Door Type)	90980–11146
	Rear Window Defogger (Except Double–Left Door Type)	90980–09042
R15	Rear Window Defogger (Double–Left Door Type)	90980–11146
	Rear Window Defogger (Except Double–Left Door Type)	90980–09042
R16	Rear Wiper Motor	90980–10795
R17	Rear Wiper Relay	90980–10173
R18	Reverse Warning Buzzer	90980–10887

Code	Part Name	Part Number
R19	Room Light No.1	90980–10906
R20	Room Light No.2	
R21	Room Light No.3	
R22	Rear Fog Light SW	90980–11533
R23	Rear Side Marker Light LH	90980–11149
R24	Rear Side Marker Light RH	
S 1	Speed Sensor (Combination Meter)	90980–11143
S 3	Starter (3RZ–FE)	90980–11400
	Starter (Except 3RZ–FE)	90980–11184
S 4	Starter (Except 3RZ–FE)	90980–09553
	Starter (3RZ–FE)	90980–09552
S 6	Step Light (Gliding Door Type)	90980–11142
S 7	Sub Radiator Fan Motor	90980–10928
S 8	Seat Belt Warning Relay	90980–10801
S 9	Speed Warning Buzzer	90980–10908
S10	Stop Light SW	90980–10916
S11	Step Light (Folding Door Type)	90980–11142
S13	Short Connector (Rear Lights)	90980–10799
S15	Shift Position Indicator SW	90980–10923
S16	Spill Valve	90980–11155
S17	Side Turn Light LH	90980–10825
S18	Side Turn Light RH	
T 1	Throttle Position Sensor	90980–11261
T 2	Tachograph	–
T 3	Turbo Pressure SW	90980–11271
T 4	Throttle Control Motor	90980–11144
T 5	Throttle Open SW	90980–11038
T 6	Timing Control Valve	90980–11153
T 7	Turbo Pressure Sensor	90980–10845
V 1	Vacuum SW	90980–11252
V 2	Vacuum SW	99141–11006
V 3	VSV (A/C Idle–Up) (1HZ, 14B)	90980–11156
	VSV (A/C Idle–Up) (15B–FT)	90980–11162
V 7	VSV (Power Control System)	90980–11156
V 8	Vacuum Sensor	90980–10845
V 9	Variable Resistor	90980–10902
V10	VRV (EGR)	90980–11162
V11	VSV (EGR Cut)	90980–11156
V12	VSV (Pressure Sensor)	90980–11149
V13	Vacuum Sensor 1 (Brake)	90980–10845
V14	Vacuum Sensor 2 (Brake)	
W 1	Water Temp. Sender	90980–11428
W 2	Water Temp. Sender	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
W 3	Water Temp. Sensor (Glow)	90980–10737
W 5	Water Temp. SW (Sub Radiator Fan)	90980–11235

Code	Part Name	Part Number
W 6	Warm–Up SW	90980–11280