■ DETAIL

1. Manual Headlight Beam Level Control System

► Function of Main Components ◄

Component	Function
Headlight Leveling Switch Assembly	Outputs control signal to the headlight leveling motor.
Headlight Assembly RH/LH - Headlight Leveling Motor	• Based on the signals received from the headlight leveling switch assembly, each motor moves the reflector in its headlight to vary its low beam angle. • Each headlight leveling motor uses a stepper motor to precisely regulate the angle of the reflector.