TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Oil leakage	Cylinder head, cylinder block or oil pump body damaged or cracked	Repair as necessary	
	Oil seal faulty	Replace oil seal	EM-48, 49, 72, 105
	Gasket faulty	Replace gasket	
Low oil pressure	Oil leskage	Repair as necessary	
	Relief valve faulty	Repair relief valve	LU-8
	Oil pump faulty	Repair oil pump	LU-9
	Engine oil poor quality	Replace engine oil	LU-6
	Crankshaft bearing faulty	Replace bearing	EM-84
	Connecting rod bearing faulty	Replace bearing	EM-84
	Oil filter clogged	Replace oil filter	LU-6
High oil pressure	Relief valve faulty	Repair relief valve	LU-8