IDLE–UP SPEED

AC06N–02

IDLE–UP SPEED INSPECTION

1. **WARM UP ENGINE**
2. **SET VEHICLE IN FOLLOWING CONDITION**
   - Blower switch high position
   - A/C switch on
   - Magnetic clutch on
3. **INSPECT IDLE UP SPEED**

   Standard:

   3B Engine 625±25 rpm
   14B Engine 800±25 rpm
   1HZ Engine 950±50 rpm

IDLE–UP SPEED ADJUSTMENT

ADJUST IDLE–UP SPEED

Adjust idle–up speed with the idle adjusting screw of the VSV.