ABBREVIATIONS USED IN THIS MANUAL

IN01D–GR

A/C	Air Conditioner
Approx.	Approximately
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
CB	Circuit Breaker
ECT	Electronic Controlled Transmission
ECU	Electronic Control Unit
Ex.	Except
FIPG	Formed in Place Gasket
FL	Fusible Link
Fr	Front
IG	Ignition
J/B	Junction Block
LED	Light Emitting Diode
LH	Left–Hand
LSPV	Load Sensing Proportioning Valve
Max.	Maximum
Min.	Minimum
MP	Multipurpose
M/T	Manual Transaxle
O/D, OD	Overdrive
PKB	Parking Brake
PS	Power Steering
RH	Right–Hand
Rr	Rear
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TEMP.	Temperature
T/M	Transmission
VSV	Vacuum Switching Valve
w/	With
w/o	Without