

PREPARATION

PR03B-01

SST (SPECIAL SERVICE TOOLS)

	09226–10010	Crankshaft Front & Rear Bearing Replacer	
	09308–00010	Oil Seal Puller	
	09330–00021	Companion Flange Holding Tool	
	09332–25010	Universal Joint Bearing Remover & Replacer	
	09557–22022	Companion Flange Remover & Replacer	

PR03C-01

EQUIPMENT

Torque wrench	

PR