

PREPARATION

SST (SPECIAL SERVICE TOOLS)

SA07U–03

	09223–15030 Oil Seal & Bearing Replacer	
	09308–00010 Oil Seal Puller	
	09510–36010 Rear Hub & Drum Puller	
	09513–36020 Rear Axle Bearing Lock Nut Wrench	
	09517–36010 Rear Axle Shaft Oil Seal Replacer	
	09608–35014 Axle Hub & Drive Pinion Bearing Tool Set	
	(09608–06020) Handle	
	(09608–06210) Rear Axle Bearing Replacer	

SA07V–03

EQUIPMENT

Dial indicator	
Torque wrench	
Spring tension gauge	