PRECAUTION

MT070–01

When working with FIPG material, you must observe the following.

- **Using a razor blade and gasket scraper, remove all the old FIPG material from the gasket surfaces.**
- **Thoroughly clean all components to remove all the loose material.**
- **Clean both sealing surfaces with a non–residue solvent.**
- **Apply the seal packing in an approx. 1 mm (0.04 in.) wide bead along the sealing surface.**
- **Part must be assembled within 10 minutes of application. Otherwise, the FIPG material must be removed and reapplied.**