ABBREVIATIONS USED IN THIS MANUAL

IN081-07

A/C	Air conditioner
AAP	Auxiliary Acceleration Pump
BTDC	Before Top Dead Center
BVSV	Bimetallic Vacuum Switching Valve
CB	Choke Breaker
CO	Choke Opener
DOHC	Double Over Head Cam
EX	Exhaust
FIPG	Formed in Place Gasket
FL	Fusible Link
H–Fuse	High Current Fuse
IG	Ignition
IN	Intake
LH	Left–Hand
Max.	Maximum
M–Fuse	Medium Current Fuse
O/S	Oversize
OVCV	Outer Vent Control Valve
PCV	Positive Crankcase Ventilation
RH	Right–Hand
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TDC	Top Dead Center
TP	Throttle Positioner
U/S	Undersize
VSV	Vacuum Switching Valve
w/	With