PRECAUTION

CH00K–00






1. **Check that the battery cables are connected to the correct terminals.**
2. **Disconnect the battery cables when the battery is given a quick charge.**
3. **Do not perform tests with a high voltage insulation resistance tester.**
4. **Never disconnect the battery while the engine is running.**

PREPARATION

CH00Q–00

SST (SPECIAL SERVICE TOOLS)

CH

	09216–00021	Belt Tension Gauge .	
	09216–00030	Belt Tension Gauge Cable .	
	09285–76010	Injection Pump Camshaft Bearing Cone Replacer	Rotor rear bearing cover for outside
	09286–46011	Injection Pump Spline Shaft Puller	Rectifier end frame for 24 V type
	09820–00021	Alternator Rear Bearing Puller	Rectifier end frame for 24 V type Rotor rear bearing
	09820–00030	Alternator Rear Bearing Replacer	Rotor rear bearing
	09820–63010	Alternator Pulley Set Nut Wrench Set	
	09950–60010	Replacer Set	
	(09951–00220)	Replacer 22	Rotor front bearing for 12 V type, 24 type for BU
	(09951–00270)	Replacer 27	Rotor front bearing for 24 type for BB
	(09951–00380)	Replacer 38	Rotor front bearing for 12 type