ABBREVIATIONS USED IN THIS MANUAL

IN060-02

A/C	Air Conditioner
ACSD	Automatic Cold Start Device
Approx.	Approximately
BTDC	Bottom Top Dead Center
CPV	Constant Pressure Valve
EX	Exhaust
FIPG	Formed in Place Gasket
G.C.C.	Gulf Cooperation Council Countries
IN	Intake
LST	Load Sensing Timer
MP	Multipurpose
O/S	Oversized
PCV	Positive Crankcase Ventilation
PS	Power Steering
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
TDC	Top Dead Center
U/S	Undersize
w/	With
w/o	Without