COOLING SYSTEM

PREPARATION

EQUIPMENT

EG12W-10

Torque wrench	

EG

COOLANT

EG12X-10

Item		Capacity	Classification
Engine coolant	w/ Heater	13.5 liters (14.2 US qts, 11.9 Imp. qts)	Ethylene—glycol base
	w/o Heater	12.4 liters (13.1 US qts, 10.9 Imp. qts)	

COOLANT CHECK

EG58P-05

1. **CHECK ENGINE COOLANT LEVEL AT RADIATOR RESERVOIR**

   The engine coolant level should be between the "LOW" and "FULL" lines.

   If low, check for leaks and add engine coolant up to the "FULL" line.

2. **CHECK ENGINE COOLANT QUALITY**

(a) Remove the radiator cap from the water outlet.

CAUTION: To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.

(b) There should not be any excessive deposits of rust or scale around the radiator cap, water outlet hole and the coolant should be free from oil.

If excessively dirty, replace the coolant.

(c) Reinstall the radiator cap.