ABBREVIATIONS USED IN THIS MANUAL

IN060–02

A/C	Air Conditioner
BTDC	Bottom Top Dead Center
FCV	Fuel Cut Valve
PCV	Positive Crankcase Ventilation
SSM	Special Service Materials
SST	Special Service Tools
VSV	Vacuum Switching Valve
w/	With
w/o	Without