TERMS

ABBREVIATIONS USED IN THIS MANUAL

IN01C–01

Abbreviations	Meaning
ABS	Anti–Lock Brake System
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
CB	Circuit Breaker
ECU	Electronic Control Unit
ELR	Emergency Locking Retractor
FIPG	Formed in Place Gasket
FL	Fusible Link
Fr	Front
IG	Ignition
J/B	Junction Block
LH	Left–Hand
LSPV	Load Sensing Proportioning Valve
Max.	Maximum
Min.	Minimum
MP	Multipurpose
M/T	Manual Transmission
PS	Power Steering
RH	Right–Hand
Rr	Rear
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TEMP.	Temperature
T/M	Transmission
w/	With
w/o	Without