BR04D–02

INSTALLATION

Installation is in the reverse order of removal (See page BR–6).

HINT:

After installation, check speed sensor signal (See page DI–3).

NOTICE:

Make sure that

- **There are no foreign objects on the sensor or the part of the knuckle to which the sensor is to be installed.**
- **The sensor is installed flat against the knuckle when you tighten the bolt.**
- **When installing the resin clips , use new ones.**