DI0BY–06

DIAGNOSTIC TROUBLE CODE CHART

NOTICE:

When removing the part, turn the ignition switch OFF.

HINT:

- Using SST 09843–18040, connect the terminals Tc and CG of DLC3.
- If any abnormality is not found when inspecting parts, inspect the ECU.
- If a malfunction code is displayed during the DTC check, check the circuit listed for that code. For details of each code, turn to the page referred to under the "See page" for respective "DTC No." in the DTC chart.

DTC No. (See Page)	Detection Item	Trouble Area
C0278 / 11 (DI–27)	Open circuit in ABS solenoid relay circuit	• ABS solenoid relay • ABS solenoid relay circuit
C0279 / 12 (DI–27)	Short circuit in ABS solenoid relay circuit	
C0273 / 13 (DI–23)	Open circuit in ABS motor relay circuit	• ABS motor relay • ABS motor relay circuit
C0274 / 14 (DI–23)	Short circuit in ABS motor relay circuit	
C0226 / 21 (DI–20)	Open or short circuit in right front solenoid circuit	• ABS actuator • SFRR or SFRH circuit
C0236 / 22 (DI–20)	Open or short circuit in left front solenoid circuit	• ABS actuator • SFLR or SFLH circuit
C0246 / 23 (DI–20)	Open or short circuit in right rear solenoid circuit	• ABS actuator • SRRR or SRRH circuit
C0256 / 24 (DI–20)	Open or short circuit in left rear solenoid circuit	• ABS actuator • SRLR or SRLH circuit
C1225 / 25 (DI–20)	Open or short circuit in SMC circuit	• ABS actuator • SMC circuit
C1227 / 27 (DI–20)	Open or short circuit in SRC circuit	• ABS actuator • SRC circuit
C0200 / 31 (DI–15)	Right front wheel speed sensor signal malfunction	• Right front, left front, right rear and left rear speed sensor • Each speed sensor circuit • Speed sensor rotor
C0205 / 32 (DI–15)	Left front wheel speed sensor signal malfunction	
C0210 / 33 (DI–15)	Right rear wheel speed sensor signal malfunction	
C0215 / 34 (DI–15)	Left rear wheel speed sensor signal malfunction	
C1241 / 41 (DI–32)	Low battery voltage or abnormally high battery voltage	• Battery • Charging system • Power source circuit
C1246 / 46 (DI–35)	Malfunction in master cylinder pressure sensor	• Master cylinder pressure sensor • Master cylinder pressure sensor circuit
C1249 / 49 (DI–38)	Open circuit in stop light switch circuit	• Stop light switch • Stop light switch circuit
C1251 / 51 (DI–41)	Pump motor is locked Open circuit in pump motor ground	• ABS actuator • ABS actuator circuit
C1265 / 65 (DI–43)	Malfunction in vacuum sensor	• Vacuum sensor • Vacuum sensor circuit

C1266 / 66 (DI–46)	Malfunction in exhaust retarder prevention signal circuit	EXO circuit
Always ON (DI–48)	Malfunction in ECU	ABS ECU