



























MANUAL TRANSMISSION (H260)








PP2BW–01

SST (Special Service Tools)

	(09316–00011)	Replacer Pipe	
	(09316–00041)	Replacer ”C”	
	09316–20011	Transfer Bearing Replacer	
	09316–60011	Transmission & Transfer Bearing Replacer	
	(09316–00011)	Replacer Pipe	
	(09316–00031)	Replacer ”B”	
	(09316–00041)	Replacer ”C”	
	09515–21010	Rear Axle Shaft Bearing Replacer	
	09527–10011	Rear Axle Shaft Bearing Remover	
	09555–55010	Differential Drive Pinion Bearing Replacer	
	09817–16011	Back–up Light Switch Tool	
	09950–00020	Bearing Remover	

	09950–40011 Puller B Set	
	(09951–04010) Hanger 150	
	(09951–04020) Hanger 200	
	(09952–04010) Slide Arm	
	(09953–04020) Center Bolt 150	
	(09953–04030) Center Bolt 200	
	(09954–04010) Arm 25	
	(09954–04020) Arm 100	
	(09954–04030) Arm 150	
	(09955–04011) Claw No.1	
	(09955–04061) Claw No.6	
	(09957–04010) Attachment	
	(09958–04011) Holder	

	09950–50012	Puller C Set	
	(09951–05010)	Hanger 150	
	(09952–05010)	Slide Arm	
	(09953–05020)	Center Bolt 150	
	(09954–05040)	Claw No.4	
	09950–60010	Replacer Set	
	(09951–00180)	Replacer 18	
	(09951–00200)	Replacer 20	
	(09951–00220)	Replacer 22	
	(09951–00290)	Replacer 29	
	(09951–00320)	Replacer 32	
	(09951–00330)	Replacer 33	
	(09951–00430)	Replacer 43	

	(09951–00480) Replacer 48	
	(09951–00570) Replacer 57	
	(09951–00620) Replacer 62	
	(09952–06010) Adapter	
	09950–60020 Replacer Set No.2	
	(09952–06010) Adapter	
	09950–70010 Handle Set	
	(09951–07100) Handle 100	
	(09951–07150) Handle 150	