FI0P6–01

INSTALLATION

Installation is in the reverse order of removal (See page FI–27).

HINT:

Install the ISC valve with a new gasket.