FI0KW–03

INSPECTION

1. REMOVE ENGINE ECU
2. INSPECT ENGINE ECU (See page DI–14)
3. REINSTALL ENGINE ECU