CO0LB–01

REMOVAL

HINT:

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.

1. DRAIN ENGINE COOLANT

2. REMOVE WATER OUTLET AND THERMOSTAT

(a) Remove the 3 bolts, water outlet and thermostat.

(b) Remove the gasket from the thermostat.