
DI9UU–01

PRE–CHECK


1. DIAGNOSIS SYSTEM


FI2547

(a) Description


- When troubleshooting Multiplex OBD (M–OBD) vehicles, the only difference from the usual troubleshooting procedure is that you connect the hand–held tester to the vehicle, and read off various data output from the vehicle's engine ECU.
- The vehicle's on–board computer lights up the check engine warning light (CHK ENG) on the instrument panel when the computer detects a malfunction in the computer itself or in drive system components. In addition to the check engine warning light lighting up when a malfunction is detected, the applicable Diagnosis Trouble Code (DTC) are recorded in the engine ECU memory (See page DI–13).

If the malfunction has been repaired, the check engine warning light goes off automatially but the DTCs remain recorded in the engine ECU memory.


N A17545

- To check the DTCs, connect the hand–held tester to Data Link Connector 3 (DLC3) on the vehicle. or read the number of blinks of the check engine warning light when TC and CG terminals on the DLC3 are connected. The hand–held tester also enables you to erase the DTCs and activate the several actuaters and check freezed frame data and vaious forms of engine data (For operating instructions, see the hand–held tester instruction book.).

- The diagnosis system operates in normal mode during normal vehicle use. It also has a check (test) mode for technicans to simulate malfunction symptoms and troubleshoot. Most DTCs use 2 trip detection logic to prevent erroneous detection and ensure thorough malfunction detection. By switching the engine ECU to check (test) mode using hand–held tester when troubleshooting, the techinician can cause the check engine warning (CHK ENG) to light up for a malfunction that is only detected once or momentarily. (Hand–held tester only) (See step 3.)
- * 2 trip detection logic
  When a logic malfunction is fist detected, the malfunction is temporaily stored in the engine ECU memory. If the same malfunction is detected again during the second drive test, this second detection cases the check engine warning (CHK ENG) to light up.
  The 2 trip repeats the same mode for 2 times. (However, the IG switch must be turned OFF between the 1st trip and 2nd trip)
- Freeze frame data:
  Freeze frame data records the engine condition when malfunction is detected.
  Because freeze frame data records the engine conditions (fuel system, calculator load, water temperature, fuel trim, engine speed, vehicle speed, etc.) when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air–fuel ratio lean or rich, etc. at the time of the malfunction.




(b) Check the DLC3.
The vehicle's engine ECU uses the ISO 14230 for communication. The terminal arrangement of DLC3 complies with SAE J1962 and matches the ISO 14230 format.

Terminal No.	Connection / Voltage or Resistance	Condition
7	Bus ⊕ Line / Pulse generation	During transmission
4	Chassis Ground / ↔ Body Ground 1 Ω or less	Always
16	Battery Positive / ↔ Body Ground 9 ~ 14 V	Always

HINT:
If your display shows ”UNABLE TO CONNECT TO VEHICLE” when you have connected the cable of the hand–held tester to DLC3, turned the ignition switch ON and operated the hand–held tester, there is a problem on the vehicle side or tool side.

- If communication is normal when the tool is connected to another vehicle, inspect DLC3 on the original vehicle.
- If communication is still not possible is when the tool is connected to another vehicle, the problem is probably in the tool itself, so consult the Service deparment listed in the tool,s instruction manual.


FI2547

2. INSPECT DIAGNOSIS (Normal Mode)

(a) Check the check engine warning light.

(1) The check engine warning (CHK ENG) comes on when the ignition switch is turned ON and the engine is not running.


HINT:
If the check engine warning (CHK ENG) does not light up, troubleshoot the combination meter.

(2) When the engine is started, the check engine warning light should go off. If the lamp remains on, the diagnosis system has detected a malfunction or abnormality in the system


(b) Check the DTC, using hand–held tester.

NOTICE:
(Hand–held tester only): When the diagnosis system is switched from normal mode to check (test) mode, it erases all DTCs and freezed frame data recorded in normal mode. So before switching modes, always check the DTCs and freezed frame data, and note them down.


(1) Prepare the hand–held tester.
(2) Connect the hand–held tester to DLC3.
(3) Turn the ignition switch ON and switch the hand–held tester main switch ON.
(4) Use the hand–held tester to check the DTCs and freezed frame data, note them down (For operating instructions, see the hand–held tester’s instruction book.).
(5) See page DI–13 to confirm the details of the DTCs.



(c) If you have no hand–held tester, perform the following step (1) to (6).
(1) Turn the ignition switch ON.
(2) Using SST, connect between terminals 13 (TC) and 4 (CG) of DLC3.
SST 09843 – 18040



(3) Read the DTC from the check engine warning light (CHK ENG).



(4) As an example, the blinking patterns for codes, normal, 12 and 31 are as shown on the illustration.
(5) Check the details of the malfunction using the DTC chart on DI–13.
(6) After completing the check, disconnect terminals 13 (TC) and 4 (CG) and turn off the display.

HINT:
In the event of 2 or more malfunction cords, indication will begin from the smaller numbered cord and continue in order to the larger.

NOTICE:
When simulatiing symptoms without a hand–held tester to check the DTCs, use normal mode. For codes on the DTCs, chart subject to ”2 trip detection logic”, turn the ignition switch OFF after the symptom is simulated the first time. Then repeat the simulation process again. When the problem has been simulated twice, the check engine warning light lights up and the DTCs, are recorded in the engine ECU.


3. INSPECT DIAGNOSIS (Check (Test) Mode)

HINT:
Hand–held tester only:
Compared to the normal mode, the check mode has an increased sensitivity to detect malfunctions.
Furthermore, the same diagnostic items which are detected in the normal mode can also be detected in the check (test) mode.

(a) Check the DTC.
(1) Initial conditions
- Battery positive voltage 11V or more.

- Throttle valve fully closed.
- Transmission in ”P” or ”N” position.
- Air conditioning switched OFF.

(2) Turn ignition switch OFF.
(3) Prepare the hand–held tester.
(4) Connect the hand–held tester to DLC3 on the at the lower right of the instrument panel.
(5) Turn the ignition switch ON and switch the push the hand–held tester ON.



(6) Switch the hand–held tester normal mode to check (test) mode. (Check that the check engine warning light (CHK ENG) flashes.)
(7) Start the engine. (The check engine warning (CHK ENG) light goes out after the engine start.)
(8) Simulate the conditions of the malfunction described by the customer.

NOTICE:
Leave the ignition switch ON until you have checked the DTC, etc.

(9) After simulating the malfunction conditions, use the hand–held tester diagnosis selector to check the DTCs and freezed frame data, etc.

HINT:
Take care not to turn the ignition switch OFF. Turning the ignition switch OFF switches the diagnosis system from check (test) mode to normal mode. so all DTCs, etc. are erased.

(10) After checking the DTCs, inspect the applicable circuit.

(b) Clear the DTC.
The following actions will erase the DTCs and freezed frame data.

- Operating the hand–held tester to erase the codes. (See the hand–held tester’s instruction book for operating in structions.)
- Disconnecting the battery terminals or EFI fuse.

NOTICE:
If the hand–held tester switches the engine ECU from normal mode to check mode or vice–versa, or if the ignition switch is turned from ON to ACC or OFF during check mode, the DTCs and freezed frame data will be erased.

4. FAIL–SAFE CHART

If any of the following codes is recorded, the engine ECU enters fail–safe mode.

DTC No.	Fail–Safe Operation	Fail–Safe Deactivation Conditions
P0105/31	• Manifold absolute pressure is fixed at 28.4 kPa (213 mmHg, 8.4 in.Hg)	Returned to normal condition
P0110/24	Intake air temp. is fixed at 20°C (68°F)	Returned to normal condition
P0115/22	Water temp. is fixed at 80°C (176°F)	Returned to normal condition
P0120/41	VTA is fixed at 0°	The following condition must be repeated at least 2 times consecutively When closed throttle position switch is ON: 0.1 V ≦ VTA and 0.95 V
P0500/42	High RPM for cut is prohibited ISC control prohibited	Returned to normal condition
P1300/14	• Fuel cut • Prohibit ignition	Returned to normal condition

5. CHECK FOR INTERMITTENT PROBLEMS

HAND–HELD TESTER only:

By putting the vehicle's engine ECU in check (test) mode, 1 trip detection logic is possible instead of 2 trip detection logic and sensitivity to detect open circuits is increased. This makes it easier to detect intermittent problems.

(1) Clear the DTC (See step 3.).
(2) Set the check (test) mode (See step 3.).
(3) Perform a simulation test (See page IN–10).
(4) Check the connector and terminal (See page IN–20).
(5) Handle the connector (See page IN–20).

6. BASIC INSPECTION

When the malfunction code is not confirmed in the DTC check, troubleshooting should be carried out in the order for all possible circuits to be considered as the causes of the problems. In many cases, by carrying out the basic engine check shown in the following flow chart, the location causing the problem can be found quickly and efficiently. Therefore, use of this check is essential in engine troubleshooting.

1	**Is battery positive voltage 11V or more when engine is stopped ?**

NO → **Charge or replace battery.**

YES

2	**Is engine cranked ?**

NO → **Proceed to problem symptoms table on page DI–18.**


YES

3	Does engine start ?

NO → Go to step 7.

YES

4	Check air filter.




PREPARATION:
Remove the air filter.
CHECK:
Visually check that the air filter is not excessively dirty or oily.
HINT:
If necessary, clean the filter with compressed air. First blow from inside thoroughly, then blow from outside of filter.

NG → **Repair or replace.**

OK

5	Check engine idle speed.



PREPARATION:
(a) Warm up engine to normal operating temperature.
(b) Switch off all accessories.
(c) Switch off air conditioning.
(d) Connect the hand–held tester to DLC3 on the vehicle.
(e) If you have no hand–held tester, connect tachometer test prove to terminal 9 (IG–) of DLC3.
SST 09843–18030

NOTICE:
As some tachometer are not compatible with this ignition system, we recommend that you confirm the compatibility of your until before use.


CHECK:
Check the idle speed.

OK:
Idle speed: 650 – 750 rpm

NG → **Proceed to problem symptoms table on page DI–18.**

OK

6	**Check ignition timing.**



PREPARATION:

(a) Warm up the engine to normal operating temperature.
(b) Keep the engine speed at idle.
(c) Using SST, connect terminals TE1 and E2 of the check connector.
SST 09843–18020
(d) Connect a timing light probe to the No.1 high–tension cord.

CHECK:

Check the ignition timing.

OK:

Ignition timing: 10 – 14° BTDC at idle

NG → **Proceed to page EM–10 and continue to troubleshoot.**

OK

Proceed to problem symptoms table on page DI–18.

7	**Check LPG regurator primary pressure.**

NG → **Proceed to continue to troubleshoot.**

OK

8	**Check for spark.**

CHECK:

Disconnect the high–tension cord from the distributor and hold the end about 12.5 mm (1/2”) from the ground. See if spark occurs while the engine is being cranked.

NOTICE:

To prevent excessive fuel being injected from the injectors during this check, don’t crank the engine for more than 1 – 2 seconds at a time.

NG → **Proceed to page IG–1 and continue to trouble-shoot.**

OK

Proceed to problem symptoms table on page DI–18.

7. ENGINE OPERATING CONDITION

NOTICE:

The values given below for ”Normal Condition” are representative values, so a vehicle may still be normal even if its value varies differ from those listed here. So do not depend solely on the ”Normal Condition” hera when deciding whether the part is faulty or not.

Hand–held tester display	Measurement Item	Normal Condition*
COOLANT TEMP	Water Temp. Sensor Value	After warming up: 80 – 95°C (176 – 203°F)
ENGINE SPD	Engine Speed	Idling: 700 ± 50 rpm
MAP	Abosolute pressure	Idling: 20 – 30 kPa Racing without load (2,500rpm): 25 – 37 kPa
VEHICLE SPD	Vehicle Speed	Vehicle stopped: 0 km/h (0 mph)
IGN ADVANCE	Ignition Advance: Ignition Timing of TDC	Idling: BTDC10 – 14°
INTAKE AIR	Intake Air Temp. Sensor Value	Equivalent to ambient temp.
INJECTOR	Fuel injection time for cylinder No. 1	Idling: 1.92 – 3.37 ms
STARTER SIG	Starter Signal	Cranking: ON
A/C SIG	A/C Switch Signal	A/C ON: ON
CTP	Closed Throttle Position	Throttle fully closed: ON
STOP LIGHT SW	Stop Light Switch Signal	Stop light switch ON: ON
PS OIL PRESS SW	Power Steering Oil Pressure Switch Signal	Turn steering wheel: ON
FC IDL	Fuel Cut Idle: Fuel cut when throttle valve fully closed, during deceleration	Fuel cut operating: ON
CYL#1 – CYL#4	Abnormal revolution variation for each cylinder	0 %
A/C CUT SIG	A/C Cut Signal	A/C S/W OFF: ON
FUEL PUMP	Fuel Pump Signal	Idling: ON
ISCS	ISC stepping position	Idling: 25 – 35 step

*: If no conditions are specifically stated for ”Idling”, it means the A/C switch is OFF and all accessory switches are OFF.