EMISSION CONTROL SYSTEM

EC0F7–02

PURPOSE

The emission control systems are installed to reduce the amount of HC, CO and NOx exhausted from the engine (2) and to prevent the atmospheric release of blow–by gas–containing HC (1).
The function of each system is shown in the following table.

System	Abbreviation	Function
(1) Positive Crankcase Ventilation	PCV	Reduce HC
(2) Three–Way Catalytic Converter	TWC	Reduce HC, CO and NOx