SOLENOID RESISTOR

FU0B3–01

ON–VEHICLE INSPECTION

INSPECT SOLENOID RESISTOR RESISTANCE

(a) Disconnect the solenoid resistor connector.
(b) Using an ohmmeter, measure the resistance between terminals.
Resistance: 5.7 – 6.3 Ω at 20 °C (68 °F)