FU08D–01

INSPECTION

1. REMOVE ENGINE ECU
2. INSPECT ENGINE ECU (See page DI–4)
3. INSTALL ENGINE ECU