IG0M0–01

REMOVAL

1. DISCONNECT HIGH–TENSION CORD FROM IGNITION COIL

2. DISCONNECT IGNITION COIL CONNECTOR

3. REMOVE IGNITION COIL

Remove the 2 bolts and ignition coil.