IG0M1–01

INSTALLATION

1. INSTALL IGNITION COIL

Install the ignition coil with 2 bolts.

Torque: 30 N·m (306 kgf·cm, 22 ft·lbf)

2. CONNECT IGNITION COIL CONNECTOR

3. CONNECT HIGH–TENSION CORD