IG0M3–01

REMOVAL

1. DISCONNECT IGNITER CONNECTOR

2. REMOVE IGNITER

Remove the 2 bolts and igniter.