IG0M4–01

INSTALLATION

1. INSTALL IGNITER

Install the igniter with 2 bolts.

2. CONNECT IGNITER CONNECTOR