LU0AZ–02

REMOVAL

1. DRAIN ENGINE OIL

2. REMOVE OIL PAN AND OIL STRAINER (See page LU–7)

3. REMOVE CHECK VALVES AND OIL NOZZLES

Remove the 4 check valves and oil nozzles.