ST0AA–04

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page ST–3).

HINT:

Use high–temperature grease to lubricate the bearings, springs, steel ball and gears when assembling the starter.