CATALYTIC CONVERTER FOR OXIDATION (CCo) SYSTEM

EC09I–02

ON–VEHICLE INSPECTION

1. INSPECT EXHAUST PIPE ASSEMBLY

(a) Check the connections for looseness or damage.

(b) Check the clamps for weakness, cracks or damage.

2. INSPECT CCo

Check for dents or damage.

If any part of the protector is damaged or dented to the extent that it contacts the CCo, repair or replace it.

3. INSPECT CCo HEAT INSULATOR

(a) Check the heat insulator for damage.

(b) Check for adequate clearance between the CCo and heat insulator.