Power Source

Audio System

1 2 3 4

9 2E
7 2F
50 2C
10A RADIO
10A ACC
38 2C
10A AM1
ACC Relay
3 2A
5 2A
9 2C
44 2B
L
W
B
1
2
40A PWR4
50A PWR2
15A PWR5
1A
B
Battery
B-R
Battery
W-B
IM1
EI
Frame LH Outside
G
R
1 AM1
ACC 3
IG1
I17
Ignition or Starter Switch Assembly
GR
R
Antenna
11 ACC
10 B
R 8
Radio Receiver Assembly
FL+ 2
FL- 8
FR+ 1
FR- 7
GND 9
P
V
LG
L
W-B
N 5
No. 1 Front Speaker Assembly LH
N 6
No. 1 Front Speaker Assembly RH
A
A
J79 Junction Connector
IN1
EK
Frame LH Outside