G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Magnetic Clutch	90980–11271
A 2	ABS Speed Sensor Front LH	90980–11073
A 3	ABS Speed Sensor Front RH	
A 4	Accel Position Sensor	90980–11930
A 5	Air Cleaner Warning SW	90980–11025
A 6	Alternator	90980–09212
A 7	Alternator	90980–11349
A 8	A/C Amplifier	90980–10801
A 9	A/C SW	90980–11280
A10	A/C Thermistor	90980–10825
A11	Accelerator Pedal Position Sensor	90980–11232
A12	Ashtray Illumination	90980–10860
A13	ABS Actuator	90980–11413
A14	ABS Actuator	90980–11698
A15	ABS Speed Sensor Rear LH (Except GVWR 5.5t)	90980–11073
	ABS Speed Sensor Rear LH (GVWR 5.5t)	90980–11773
A16	ABS Speed Sensor Rear RH (Except GVWR 5.5t)	90980–11073
	ABS Speed Sensor Rear RH (GVWR 5.5t)	90980–11773
B 1	Back–Up Light SW	90980–11250
B 2	Brake Vacuum Warning SW	90980–11252
B 3	Blower Motor	90980–10214
B 4	Blower Resistor	90980–10171
B 5	Brake Fluid Level Warning SW	90980–10214
B 6	Brake Vacuum Warning Buzzer	90980–10825
C 1	Camshaft Position Sensor	90980–10598
C 2	Condenser Fan Motor and Resistor	90980–10841
C 3	Crankshaft Position Sensor	90980–10598
C 4	Cigarette Lighter	90980–10760
C 5	Combination Meter	82824–28140
C 6	Combination Meter	82824–28160
C 7	Combination SW	90980–10803
C 8	Combination SW	90980–11913
C 9	Condenser Fan Fuse	90980–10214
D 1	Diode (A/C)	90980–11608
D 2	Diode (Pressure Charge Valve)	90980–10962
D 3	DLC3	90980–11665
D 4	Door Lock Control Relay	90980–10819
D 5	Door Courtesy SW (Driver's Side)	90980–10871
D 6	Door Lock Control SW	90980–11245
D 7	Door Lock Motor (Passenger's Side)	90980–11150
D 8	DC/DC Converter	90980–10997
E 1	EFI Water Temp. Sensor	90980–11451
	Water Temp. Sender	
E 2	Engine Oil Level Warning SW	90980–10532

Code	Part Name	Part Number
E 3	Exhaust Brake Solenoid	90980–10923
E 4	Engine ECU	90980–11421
E 5	Engine ECU	90980–11476
E 6	Engine ECU	90980–11637
E 7	Engine ECU	90980–11638
E 8	Exhaust Brake Accelerator Pedal SW	90980–10825
E 9	Exhaust Brake Clutch SW	90980–10935
F 1	Front Clearance Light LH	90980–11020
F 2	Front Clearance Light RH	
F 3	Front Fog Light LH	90980–11019
F 4	Front Fog Light RH	
F 5	Front Turn Signal Light LH	90980–11003
F 6	Front Turn Signal Light RH	
F 7	Fuel Filter Warning SW	90980–10737
F 8	Fuel Pressure Sensor	82580–6630A
F 9	Fuel Sender	90980–10834
F10	Fuel Temp. Sensor	90980–10737
F11	Flasher Relay	90980–10173
F12	Front Side Turn Signal Light LH	90980–11019
F13	Front Side Turn Signal Light RH	
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight LH	90980–11314
H 4	Headlight RH	
H 5	Horn (High)	90980–10619
H 6	Horn (Low)	
H 7	Hazard SW	90980–10801
H 8	Headlight Beam Level Control SW	90980–11296
H 9	Heater Control SW	90980–10714
I 1	Injection Pump Correction Resistor	–
I 2	Injector No.1	82580–7990A
I 3	Injector No.2	
I 4	Injector No.3	
I 5	Injector No.4	
I 6	Ignition SW	90980–11537
I 7	Interior Light	90980–11918
J 1	Junction Connector	90980–10830
J 2	Junction Connector	90980–11542
J 3	Junction Connector	
J 4	Junction Connector	
J 5	Junction Connector	
J 6	Junction Connector	
J 7	Junction Connector	90980–10803
J 8	Junction Connector	
J 9	Junction Connector	90980–10807

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
J10	Junction Connector	90980–11915
J11	Junction Connector	
J12	Junction Connector	90980–11542
J13	Junction Connector	90980–10803
J14	Junction Connector	90980–10807
J15	Junction Connector	90980–11542
J16	Junction Connector	90980–10803
L 1	License Plate Light LH	90980–10498
L 2	License Plate Light RH	
M 1	Master Cylinder Pressure Sensor	90980–10845
N 1	Neutral Position SW	90980–11075
O 1	Oil Pressure SW	90980–11363
P 1	Pressure SW	90980–10943
P 2	PTO Solenoid Valve	90980–10923
P 3	PTO Transmission Neutral Position SW	90980–10887
P 4	Power Outlet (Room)	90980–10171
P 5	PTO Clutch SW	90980–10860
P 6	PTO SW	90980–10997
P 7	Parking Brake SW	90980–10795
P 8	Power Outlet	90980–11178
P 9	Power Window Control SW (Passenger's Side)	90980–10631
P10	Power Window Master SW	90980–10799
P11	Power Window Motor (Driver's Side)	90980–11003
P12	Power Window Motor (Passenger's Side)	
R 1	Radio and Player	90980–10997
R 2	Rear Fog Light SW	90980–11533
R 3	Rear Combination Light LH	90980–10173
R 4	Rear Combination Light RH	

Code	Part Name	Part Number
R 5	Rear Fog Light	90980–11051
R 6	Reverse Warning Buzzer	90980–11156
S 1	Short Connector	82580–7980A
S 2	Short Connector	82580–8230A
S 3	Speed Sensor (Combination Meter)	90980–11143
S 4	Starter	–
S 5	Starter	90980–11184
S 6	Starter Relay	99141–13006
S 7	Starter Relay	
S 8	Starter Relay	90980–11299
S 9	Suction Control Valve No.1	90980–10720
S10	Suction Control Valve No.2	
S11	Skid Control ECU	90980–11390
S12	Skid Control ECU	90980–11391
S13	Skid Control ECU	90980–11408
S14	Skid Control ECU	90980–11392
S15	Stop Light SW	90980–10916
S16	Speaker LH	90980–10935
S17	Speaker RH	
S18	Short Pin (PTO SW)	90980–11102
T 1	Tilt Cab Control SW	90980–11075
T 2	Turbo Pressure Sensor	82580–6630A
T 3	Tachograph	90980–10797
V 1	Vacuum Sensor No.1	90980–10845
V 2	Vacuum Sensor No.2	
W 1	Water Temp. SW	90980–10892
W 2	Wiper Motor	90980–11599
W 3	Washer Motor	90980–10214