ABBREVIATIONS

The following abbreviations are used in this manual.

A/C	=	Air Conditioner
ABS	=	Anti–Lock Brake System
CD	=	Compact Disc
COMB.	=	Combination
DC	=	Direct Current
DLC3	=	Data Link Connector 3
ECU	=	Electronic Control Unit
EDU	=	Electronic Driving Unit
EFI	=	Electronic Fuel Injection
EGR	=	Exhaust Gas Recirculation
ES	=	Easy & Smooth
FL	=	Fusible Link
GVWR	=	Gross Vehicle Weight Rating
INT	=	Intermittent
J/B	=	Junction Block
LCD	=	Liquid Crystal Display
LH	=	Left–Hand
LHD	=	Left–Hand Drive
PTO	=	Power Take Off
R/B	=	Relay Block
RH	=	Right–Hand
RHD	=	Right–Hand Drive
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
VRV	=	Vacuum Regulating Valve
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.